

BIOCLEAN DB

Pouch-style Facemask with Neck Guard

BDBN-G

About

The BioClean DB Pouch-style Facemask features a large breathing chamber for increased wearer comfort. Made from cleanroom compatible materials the BioClean DB facemask features an integrated neck guard to provide additional coverage reducing the risk of cross-contamination.

Materials

INNER FACING LAYER:

Non-woven spunbonded polyester
(hygroscopic)

FILTER LAYER:

Meltblown polypropylene

OUTER FACING LAYER:

Non-woven spunbonded polyester
(hydrophobic)

FASTENINGS:

Tubular knitted polyurethane Spandex
yarn headloops

NECK GUARD:

Non-woven spunbonded polyester

NOSE-BAND:

Plastic coated steel

Features

- High bacterial & particle filtration efficiency
- Extra long neck guard
- Large breathing chamber
- Ultrasonically sealed edges
- Fully enclosed malleable nose-band

ISO CLASS 4 COMPATIBLE

LARGE BREATHING CHAMBER

INTEGRAL NECK GUARD



Ansell

Quality Standards

- Manufactured in a facility holding ISO 9001:2015
- Processed in an NEBB certified ISO Class 4 cleanroom environment
- Sampling and inspection in accordance with ISO 2859-3:1992

Physical Properties

COLOUR	White
STYLE	Headloops
LENGTH (± 5mm)	Facemask: 301mm Neck Guard: 245mm
WIDTH (± 5mm)	Facemask: 100mm Neck Guard: 210mm

Performance Information

COMPATIBILITY	ISO Class 4
PARTICLE FILTRATION EFFICIENCY (PFE)@ 0.3 MICRON	99.9%
BACTERIAL FILTRATION EFFICIENCY (BFE) @ 3.0 MICRON	99.9%
DIFFERENTIAL PRESSURE (ΔP), mm H ₂ O/cm ²	3.0

TO ORDER

Re-order code

BDBN-G

Packing

50 pieces per sealed inner PE bag; one inner bag per sealed outer PE bag; six outer bags per lined carton (300 pieces)

For additional information visit us at www.bioclean.com, or contact us at;

Nitritex Ltd
Ground Floor, 15 Kings
Court
Willie Snaith Road,
Newmarket,
Suffolk, CB8 7SG,
United Kingdom
Tel: +44 1638 663338
BDBN-G/1903/PDS20

Ansell US
111 Wood Avenue South
Suite 210
Iselin, NJ 08830
USA
Tel: +1 800 800 0444

Nitritex (M) Sdn.Bhd
2 Jalan Jurunilai U1/20
Seksyen U1, Hicom Glenmarie Industrial Park
40150 Shah Alam, Selangor
Malaysia
Tel: +603 5569 3857/3859

Ansell

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of facemasks/veils for a specific application.

Ansell, ® and TM are trademarks owned by Ansell Limited or one of its affiliates. © 2012 – 2019 Ansell Limited. All Rights Reserved.