



BioClean-D™ Sleeve Covers - Sterile S-BDSC-L

Longer-length sterile disposable sleeve covers, for more comprehensive personal protection

- **Enhanced protection:** BioClean-D™ Sleeve Covers S-BDSC-L sterile sleeve covers are longer than standard Ansell alternatives (at an average length of 480mm), boosting protective coverage over the arms
- **ESD properties:** Their material is antistatic-coated, limiting the risk of electrostatic damage or interference
- **Reduced contamination risks:** These disposable sleeve covers are also made from low-linting lightweight CleanTough™ material, for enhanced comfort and fewer contamination risks
- **Optimized fit:** They also feature an elasticated opening, granting wearers a firmer, more secure fit



Key Features and Benefits

- **Longer length (480mm):** Enhanced coverage and protection
- **Antistatic coating:** Controlled electrostatic dissipation
- **Low-linting lightweight material:** Lower contamination risks

Industries

- Controlled and Critical Environments
- Production and Manufacturing
- Pharmaceutical Manufacturing
- Biotechnology Manufacturing
- Medical Device Manufacturing





BioClean-D™ Sleeve Covers - Sterile S-BDSC-L

TECHNICAL DATA SHEET

PRODUCT INFORMATION

Material	CleanTough™
Audit Standards	Manufacturing QMS Audit Standards ISO 9001, PPE Regulation 2016 425 Module D
Standards	ASTM F739, Partial Body Protection Only, CE 0598, EN 1149-5:2008, EN 1149-5:2018, EN 13934-1, EN 13935-2, EN 530, EN 6530, EN 7854, EN 863, EN 9073-4, EN ISO 13688:2013, EN ISO 13688:2013+A1:2021, EN ISO 14325, ISO 11137-1:2006, Category III, EN 13034:2005 + A1:2009, EN 13034:2005 + A1:2009
Packaging Overview	One pair per sealed inner PE bag; 15 inner bags per sealed outer PE bag; six outer bags per lined carton (90 pairs)
Country Of Origin	China
Sterilization Method	GAMMA irradiation (25 kGy)
Sterilization Minimum Dose	25kGy
Sterility Assurance Level	10 ⁻⁶
Cleanroom Class	Class 10/ISO 4 & EU GMP Grade A
Shelf Life	Three (3) years from date of manufacture
Construction	Bound seams with single needle stitching
Characteristics	*NOTE: BioClean CleanTough material is static dissipative and, with a charge half decay time of 0.07 sec, and so are ideal for use in a static-safe environment.

PARTICLE SHEDDING TEST RESULTS

TEST	RESULT
Particle Shedding (Helmke Drum Test)	≥ 0.5µm (counts/min) <260

ASTM F739-12 TEST METHOD RESULTS

DRUG	Mean Breakthrough Time (MBT), Minutes Breakthrough of the test chemical is deemed to have occurred when the permeation rate has reached 0.1 µg/cm ² /min
CISPLATIN	>240
CARMUSTINE	<6
CYCLOPHOSHAMIDE	217 (275,162,215)
DOXORUBICINHYDROCHLORIDE	>240
5-FLUOROURACIL	>240
METHOTREXATE	>240
ETOPOSIDE	>240
PACLITAXEL	<10
THIOTEPA	30 (28,30,33)

Results achieved under controlled laboratory conditions, by accredited external testing laboratory.

SIZE CHART

Universal long length min. 480mm



BioClean-D™ Sleeve Covers - Sterile S-BDSC-L

MATERIAL PERFORMANCE TEST RESULTS

TEST	RESULT	PERFORMANCE CLASS
Abrasion Resistance	10 to 100 cycles	1
Flex Cracking Resistance	5,000 to 15,000 cycles	3
Puncture Resistance	8 N	1
Trapezoidal Tear Resistance Cross Direction (CD)	CD 29.3 N	2
Trapezoidal Tear Resistance Machine Direction (MD)	MD 55.5 N	3
Tensile Strength Cross Direction (CD)	CD 48 N	1
Tensile Strength Machine Direction (MD)	MD 97 N	2
Repellence to Liquids – 30% H ₂ SO ₄	96.3%	3
Repellence to Liquids – 10% NaOH	97.6%	3
Repellence to Liquids – O-Xylene	95.7%	2
Repellence to Liquids – Butan-1-ol	96.6%	3
Penetration by Liquids – 30% H ₂ SO ₄	0%	3
Penetration by Liquids – 10% NaOH	0%	3
Penetration by Liquids – O-Xylene	0%	3
Penetration by Liquids – Butan-1-ol	0%	3
Seam Strength ²	70 N	2
Electrostatic Charge Half Decay Time, t ₅₀ (secs)	0.07	PASS

1. Seam not destroyed

For additional information visit us at www.ansell.com, or call us at

Europe, Middle East & Africa Region

Ansell Healthcare Europe NV
T: +32 (0) 2 528 74 00
F: +32 (0) 2 528 74 01

Asia Pacific Region

Ansell Global Trading Center
T: +603 8310 6688
F: +603 8310 6699

North America Region

Ansell Healthcare Products LLC
US T: +1 800 800 0444
US F: +1 800 800 0445
CA T: +1-800-363-8340

Latin America & Caribbean Region

Ansell Commercial Mexico S.A. de C.V.
T: +52 442 248 1544 / 248 3133

Australia

Ansell Limited
T: +61 1800 337 041
F: +61 1800 803 578

UK

Ansell Nitritex
T: +44 1638 663338
F: +44 1638 668890

Performance Standards and Regulatory Compliance



CE 0598



ISO 11137-1



TYPE PB [6]



TYPE PB [6]

Ansell, ® and ™ are trademarks owned by Ansell Limited or one of its affiliates. US Patented and US and non-US Patents Pending: www.ansell.com/patentmarking © 2024 Ansell Limited. All Rights Reserved.

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of gloves for a specific application.

Please see product validation pack or contact Ansell customer service for specific data on use of garments with cytotoxic drugs. Garments used for protection against such drugs must be selected specifically for the type of chemicals used.

